Acer Projector

P6600/F261/PM-WU01/P6500/F251/ PM-801/P6200/F211/PM-X01/ P6200S/F211S/PM-X01S Series User's Guide

Downloaded from www.Manualslib.com manuals search engine

Copyright © 2015. Acer Incorporated.
All Rights Reserved.

Acer Projector User's Guide
Original Issue: 08/2015

Changes may be made periodically to the information in this publication without obligation to notify any person of such revisions or changes. Such changes will be incorporated in new editions of this manual or supplementary documents and publications. This company makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims the implied warranties of merchantability or fitness for a particular purpose.

Record the model number, serial number, purchase date and place of purchase information in the space provided below. The serial number and model number are recorded on the label affixed to your projector. All correspondence concerning your unit should include the serial number, model number and purchase information.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronically, mechanically, by photocopy, recording or otherwise, without the prior written permission of Acer Incorporated.

Model number: _____

Serial number: _____

Date of purchase: _____

Place of purchase: _____

Acer and the Acer logo are registered trademarks of Acer Incorporated. Other companies' product names or trademarks are used herein for identification purposes only and belong to their respective companies.

"HDMI™, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC."

Downloaded from www.Manualslib.com manuals search engine

Information for your safety and comfort

Read these instructions carefully. Keep this document for future reference. Follow all warnings and instructions marked on the product.

Turning the product off before cleaning

Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

Caution for plug as disconnecting device

Observe the following guidelines when connecting and disconnecting power to the external power supply unit:

- Install the power supply unit before connecting the power cord to the AC power outlet.
- Unplug the power cord before removing the power supply unit from the projector.
- If the system has multiple sources of power, disconnect power from the system by unplugging all power cords from the power supplies.

Caution for Accessibility

Be sure that the power outlet you plug the power cord into is easily accessible and located as close to the equipment operator as possible. When you need to disconnect power to the equipment, be sure to unplug the power cord from the electrical outlet.

Warnings!

- Do not use this product near water.
- Do not place this product on an unstable cart, stand or table. If the product falls, it could be seriously damaged.
- Slots and openings are provided for ventilation to ensure reliable operation of the product and to protect it from overheating. These openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug or other similar surface.

This product should never be placed near or over a radiator or heat register, or in a built-in installation unless proper ventilation is provided.

- Never push objects of any kind into this product through cabinet slots as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind onto or into the product.

Downloaded from www.Manualslib.com manuals search engine

- To avoid damage of internal components and to prevent battery leakage, do not place the product on a vibrating surface.
- Never use it under sporting, exercising, or any vibrating environment which will probably cause unexpected short current or damage rotor devices, lamp.

Using electrical power

- This product should be operated from the type of power indicated on the marking label. If you are not sure of the type of power available, consult your dealer or local power company.
- Do not allow anything to rest on the power cord. Do not locate this product where people will walk on the cord.
- If an extension cord is used with this product, make sure that the total ampere rating of the equipment plugged into the extension cord does not exceed the extension cord ampere rating. Also, make sure that the total rating of all products plugged into the wall outlet does not exceed the fuse rating.
- Do not overload a power outlet, strip or receptacle by plugging in too many devices. The overall system load must not exceed 80% of the branch circuit rating. If power strips are used, the load should not exceed 80% of the power strip's input rating.
- This product's AC adapter is equipped with a three-wire grounded plug. The plug only fits in a grounded power outlet. Make sure the power outlet is properly grounded before inserting the AC adapter plug. Do not insert the plug into a non-grounded power outlet. Contact your electrician for details.

Warning! The grounding pin is a safety feature. Using a power outlet that is not properly grounded may result in electric shock and/or injury.

Note: The grounding pin also provides good protection from unexpected noise produced by other nearby electrical devices that may interfere with the performance of this product.

- Use the product only with the supplied power supply cord set. If you need to replace the power cord set, make sure that the new power cord meets the following requirements: detachable type, UL listed/CSA certified, VDE approved or its equivalent, 4.5 meters (15 feet) maximum length.

Downloaded from www.Manualslib.com manuals search engine

Product servicing

Do not attempt to service this product yourself, as opening or removing covers may expose you to dangerous voltage points or other risks. Refer all servicing to qualified service personnel.

Unplug this product from the wall outlet and refer servicing to qualified service personnel when:

- the power cord or plug is damaged, cut or frayed
- liquid was spilled into the product
- the product was exposed to rain or water
- the product has been dropped or the case has been damaged
- the product exhibits a distinct change in performance, indicating a need for service
- the product does not operate normally after following the operating instructions

Note: Adjust only those controls that are covered by the operating instructions, since improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal condition.

Warning! For safety reasons, do not use non-compliant parts when adding or changing components. Consult your reseller for purchase options.

Your device and its enhancements may contain small parts. Keep them out of the reach of small children.

Additional safety information

- Do not look into the projector's lens when the lamp is on. The bright may hurt your eyes.
- Turn on the projector first and then signal sources
- Do not place the product in following environments:
  - Space that is poorly ventilated or confined. At least 50cm clearance from walls and free flow of air around the projector is necessary.
  - Locations where temperatures may become excessively high, such as inside of a car with all windows rolled up.
  - Locations where excessive humidity, dust, or cigarette smoke may contaminate optical components, shortening the life span and darkening the image.
  - Locations near fire alarms.
  - Locations with an ambient temperature above 40 °C/104 °F.
  - Locations where the altitudes are higher than 10000 feet.
- Unplug immediately if there is something wrong with your projector. Do not operate if smoke, strange noise or odor comes out of your projector. It

Downloaded from www.Manualslib.com manuals search engine

might cause fire or electric shock. In this case, unplug immediately and contact your dealer.

- Do not keep using this product to break or drop it. In this case contact your dealer for inspection.
- Do not face the projector lens to the sun. It can lead to fire.
- When switching the projector off, suggest to ensure the projector completes its cooling cycle before disconnecting power.
- Do not frequently turn off the main power abruptly or unplug the projector during operation. The best way is to wait for the fan to turn off before turning main power off.
- Do not touch air outlet grille and bottom plate which becomes hot.
- Clean the air filter frequently if have. The temperature inside may rise and cause damage when the filter/ventilation slots clogged with dirt or dust.
- Do not look into the air outlet grille when projector is operating. It may hurt your eyes.
- Always open the lens shutter or remove the lens cap when the projector is on.
- Do not block the projector lens with any object when the projector is under operation as this could cause the object to become heated and deformed or even cause a fire. To temporarily turn off the lamp, press **HIDE** on the remote control.
- The lamp becomes extremely hot during operation. Allow the projector to cool for approximately 45 minutes prior to removing the lamp assembly for replacement.
- Do not operate lamps beyond the rated lamp life. It could cause it to break on rare occasions.
- Never replace the lamp assembly or any electronic components unless the projector is unplugged.
- The product will detect the life of the lamp itself. Please be sure to change the lamp when is showing warning message.
- When changing the lamp, please allow unit to cool down, and follow all changing instructions.
- Reset the "Lamp Hour Reset" function from the Onscreen display "Management" menu after replacing the lamp module.
- Do not attempt to disassemble this projector. There are dangerous high voltages inside which may hurt you. The only user serviceable part is the lamp which has its own removable cover. Refer servicing only to suitable qualified professional service personnel.
- Do not stand the projector on end vertically. It may cause the projector to fall over, causing injury or damage.
- This product is capable of displaying inverted images for ceiling mount installation. Only use acer ceiling mount kit for mounting the projector and ensure it is securely installed.

Downloaded from www.Manualslib.com manuals search engine

Caution for Listening

To protect your hearing, follow these instructions.

- Increase the volume gradually until you can hear clearly and comfortably.
- Do not increase the volume level after your ears have adjusted.
- Do not listen to music at high volumes for extended periods.
- Do not increase the volume to block out noisy surroundings.
- Decrease the volume if you can't hear people speaking near you.

Disposal instructions

Do not throw this electronic device into the trash when discarding. To minimize pollution and ensure utmost protection of the global environment, please recycle. For more information on the Waste from Electrical and Electronics Equipment (WEEE) regulations, visit
http://www.acer-group.com/public/Sustainability/sustainability01.htm

Mercury advisory

For projectors or electronic products containing an LCD/CRT monitor or display:



Lamp(s) inside this product contain mercury and must be recycled or disposed of according to local, state or federal laws. For more information, contact the Electronic Industries Alliance at www.eiae.org. For lamp-specific disposal information, check www.lamprecycle.org

RISK GROUP 2
CAUTION
Possibly hazardous optical radiation emitted from this product
Groupe de risque 2
ATTENTION
Rayonnement optique éventuellement dangereux émis par ce produit

Downloaded from www.Manualslib.com manuals search engine

First things first

Usage Notes

Do:

- Turn off the product before cleaning.
- Use a soft cloth moistened with mild detergent to clean the display housing.
- Disconnect the power plug from AC outlet if the product is not being used for a long period of time.

Don't:

- Block the slots and openings on the unit provided for ventilation.
- Use abrasive cleaners, waxes or solvents to clean the unit.
- Use under the following conditions:
  - In extremely hot, cold or humid environments.
  - In areas susceptible to excessive dust and dirt.
  - Near any appliance that generates a strong magnetic field.
  - Place In direct sunlight.

Precautions

Follow all warnings, precautions and maintenance as recommended in this user's guide to maximize the life of your unit.

Warning:

- Do not look into the projector's lens when the lamp is on. The bright light may hurt your eyes.
- To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.
- Please do not open or disassemble the product as this may cause electric shock.
- When changing the lamp, please allow unit to cool down, and follow all changing instructions.
- This product will detect the life of the lamp itself. Please be sure to change the lamp when it shows warning messages.
- Reset the "Lamp Hour Reset" function from the Onscreen display "Management" menu after replacing the lamp module.
- When switching the projector off, please ensure the projector completes its cooling cycle before disconnecting power.
- Turn on the projector first and then the signal sources.
- Do not use lens cap when projector is in operation.
- When the lamp reaches the end of its life, it will burn out and may make a loud popping sound. If this happens, the projector will not turn back on until the lamp module has been replaced. To replace the lamp, follow the procedures listed under "Replacing the Lamp".

Downloaded from www.Manualslib.com manuals search engine

Contents

Information for your safety and comfort iii

First things first viii

- Usage Notes viii
- Precautions viii

Introduction 1

- Product Features 1
- Package Overview 3
- Projector Overview 4
  - Projector Outlook 4
  - Control Panel 6
  - Remote Control Layout 7
  - MHL (Mobile High-Definition Link) Control 9

Getting Started 10

- Connecting the Projector 10
- Turning the Projector On/Off 12
  - Turning on the Projector 12
  - Turning the projector off 13
- Adjusting the Projected Image 14
  - Adjusting the Height of Projected Image 14
  - How to optimize image size and distance 15
  - How to get a preferred image size by adjusting distance and zoom 18
  - How to get a preferred image position by adjusting lens shift 21

User Controls 23

- Installation menu 23
- Onscreen Display (OSD) Menus 25
- Color 26
- Image 28
- Setting 30
- Management 32
- Audio 33
- 3D 34

Downloaded from www.Manualslib.com manuals search engine

Language 34
Acer LAN webpage management 35
How to login in 35
Home 36
Control Panel 36
Network Setting 37
Alert Setting 37
Logout 38
Appendices 39
Troubleshooting 39
LED & Alarm Definition Listing 43
How to install cable management 44
Cleaning and replacing the dust filters 45
Replacing the Lamp 46
Ceiling Mount Installation 48
Specifications 51
Compatibility modes 53
Regulations and safety notices 58

Downloaded from www.Manualslib.com manuals search engine

English

Introduction

Product Features

This product is a single-chip DLP® projector. Outstanding features include:

- DLP® technology
- P6200/F211/PM-X01/P6200S/F211S/PM-X01S series: Native 1024 x 768 XGA resolution
  P6S00/F2S1/PM-801 series: 1920x1080 1080p resolution
  P6600/F261/PM-WU01 series: True 1920x1200 WUXGA resolution
  Full/4:3/16:9/L.Box aspect ratio supported
- Enables projecting 3D content via DLP Link Technology: Blue-Ray 3D supported and nVidia 3DTV Play Ready
- Acer ColorBoost technology delivers nature's true colors for vivid, life-like images
- High brightness and contrast ratio
- Acer LumiSense+ technology can intelligently optimizes the brightness and color saturation of projected image based on actual ambient light.
- Versatile display modes (Bright, Presentation, Standard, Video, User) enable optimum performance in any situation
- NTSC / PAL / SECAM compatible and HDTV (720p, 1080i, 1080p) supported
- Lower power consumption and economy (ECO) mode extend lamp life
- Acer EcoProjeciton Technology delivers Intelligent power management approach and physical efficiency improvement
- Equipped with HDMI™ & MHL connection supporting HDCP
- Support HDMI CEC function
- Advanced digital keystone and 4-corner correction optimizes presentations
- Smart detection delivers quick, intelligent source detection
- Multi-language onscreen display (OSD) menus
- Manual focus projection lens zooms up to 1.36x / 1.59x
- 2x digital zoom and pan function
- Microsoft® Windows® 2000, XP, Vista®, Windows 7, Windows 8, Macintosh® OS compliant
- Support MHL V2.0 signal display
- Support LumiSense+
- Built-in Two 10 Watts speaker
- Manual lens vertical shift adjustment
- Cable management

Downloaded from www.Manualslib.com manuals search engine

Note: Functions vary depending on model definition.

Downloaded from www.Manualslib.com manuals search engine

English

Package Overview

This projector comes with all the items shown below. Check to make sure your unit is complete. Contact your dealer immediately if any thing is missing.



Projector



Power cord

VGA cable

Security card

User's guide

Quick start guide



Carrying case



Dust filters
(option)

Remote control

2 x Batteries
(option)



Cable management cover



WirelessHD-Kit
(option)



WirelessCAST
(option)

Downloaded from www.Manualslib.com manuals search engine

English

Projector Overview

Projector Outlook

Front / upper side



#	Description	#	Description
1	Dust filter cover	7	Lamp cover
2	Control panel	8	Projection lens
3	Power button	9	Lens Cap
4	Zoom lever	10	Tilt adjusting wheels
5	Lens shift control ring	11	Ambient light sensor
6	Focus ring	12	Remote control receiver

Downloaded from www.Manualslib.com manuals search engine

Right / Rear side



#	Description	#	Description
1	Power socket	11	RS232 connector
2	5V DC output connector	12	YPbPr/YCbCr input connector
3	HD BaseT	13	S-Video input connector
4	LAN (RJ45 Port for 10/100M Ethernet)	14	Composite video input connector
5	Mini USB Ctrl connector (for firmware upgrade and USB display)	15	Audio in connector (RCA)
6	Kensington™ lock port	16	Audio in connector
7	HDMI 2 connector	17	Audio out connector
8	HDMI/MHL connector (HDMI/MHL, HDMI 1/MHL)	18	12V DC output connector
9	PC analog signal/HDTV/component video input connector (VGA, VGA IN, VGA IN 1, VGA IN 2)	19	3.5mm Microphone Input
10	Monitor loop-through output connector (for VGA IN 1 only)		

Note: Functions vary depending on model definition.

Downloaded from www.Manualslib.com manuals search engine

English

Control Panel



#	Icon	Function	Description
1		Four directional select keys	Use ▲▼▶◀ to select items or make adjustments to your selection.
2		MENU	• Press "MENU" to launch the Onscreen display (OSD) menu, back to the previous step for the OSD menu operation or exit the OSD menu. • Confirm your selection of items.
3		SOURCE	Changes the active source.
4		LAMP	Lamp Indicator LED
S		TEMP	Temp Indicator LED
6		RESYNC	Automatically synchronizes the projector to the input source.
7		MODE	Press "MODE" to select the display mode from Bright, Standard, Movie, Dark Cinema, Game, Sport and User.
8	▲ ▼	Keystone	Adjusts the image to compensate for distortion caused by tilting the projector.
9	⏻	POWER	• Power Indicator LED • See the contents in "Turning the Projector On/Off" section.

Note: Functions vary depending on model definition.

Downloaded from www.Manualslib.com manuals search engine

Remote Control Layout



#	Icon	Function	Description
1		Infrared transmitter	Sends signals to the projector.
2		POWER	Refer to the "**Turning the Projector On/Off**" section.
3		3D	Press "3D" to select 3D models.
4		SOURCE	Changes the active source.
S		MODE	Press "MODE" to select the display mode from Bright, Standard, Movie, Dark Cinema, Game, Sport and User.
6		HIDE	Momentarily turns off the video. Press "**HIDE**" to hide the image, press again to display the image.
7		MEDIA_SETUP	No function
B		RATIO	To choose the desired aspect ratio.
9		ZOOM	Zooms the projector display in or out.
10		FREEZE	To pause the screen image.
11		MENU	▪ Press "MENU" to launch the Onscreen display (OSD) menu, back to the previous step for the OSD menu operation or exit the OSD menu. • Confirm your selection of items.
12		KEYSTONE	Adjusts the image to compensate for distortion caused by tilting the projector.
13		Four directional select keys	Use up, down, left, right buttons to select items or make adjustments to your selection.

Downloaded from www.Manualslib.com manuals search engine

#	Icon	Function	Description
14	⏮ ◀◀	Pre./Rewind	No function
	ENTER ►/II	Enter/ Play/ Pause	No function
	BACK ■	Back/Stop	No function
	⏭ ►►	Next/Fast forward	No function
15		KeyPad 0~9	Press "0~9" to input a password in the "Security" OSD.
16		PgUp/PgDn	For computer mode only. Use this button to select the next or previous page. This function is only available when USB Ctrl connector (mini type B) is connected to a computer via a USB cable.
17		COMPONENT	Press "COMPONENT" to change source to Component video. This connection supports YPbPr (480p/576p/720p/1080i) and YCbCr (480i/576i)
18		VIDEO	To change source to COMPOSITE VIDEO.
19		VGA	Press "VGA" to change source to the VGA connector. This connector supports analog RGB, YPbPr (480p/576p/720p/1080i), YCbCr (480i/576i) and RGBsync.
20		S-VIDEO	No function
21		SD/USB A	No function
22		USB B	For USB control and firmware upgrade.
23		HDMI/DVI	To change source to HDMI/MHL. (no DVI function)
24		LAN/WiFi	No function
25		Laser pointer	Aim the remote at the viewing screen
26		Laser button	Aim the remote at the viewing screen, press and hold this button to activate the laser pointer. This function is not supported in Japanese market

Note: Functions vary depending on model definition.

Downloaded from www.Manualslib.com manuals search engine

MHL (Mobile High-Definition Link) Control



#	Icon	Component	Description
1		MODE	• Press "MODE" button for one second to activate the MHL Control Mode. • To exit, press the "MODE" button again
2		SOURCE	Press the "SOURCE" button to toggle between Navigation or Numeric mode.
3		MENU	Press to launch the root memu (only for **Navigation** mode)
4		Direction Keys	Use up, down, left, right buttons to select items or make adjustments to your selection. (only for **Navigation** mode)
S	ENTER ►/II	Select	To select the file. (only for **Navigation** mode)
6	BACK ■	Exit	To exit the file. (only for **Navigation** mode)
7	PgUp PgDn	PgUp/PgDn	Use the button to select the next or previous page. (only for **Navigation** mode)
8		KeyPad 0~9	Number buttons (only for **Numeric** mode)

Note: Functions vary depending on model definition.

Downloaded from www.Manualslib.com manuals search engine

English

Getting Started

Connecting the Projector



#	Description	#	Description
1	Power cord	9	Composite video cable
2	USB cable for charging device	10	Audio cable Jack/RCA
3	LAN cable	11	12V DC cable
4	MHL cable (MicroUSB to HDMI)	12	Microphone cable
S	HDMI cable	13	RS232 cable
6	VGA cable	14	USB cable
7	VGA to component/HDTV adapter	1S	3 RCA component cable
B	S-Video cable		

Downloaded from www.Manualslib.com manuals search engine

Note: To ensure the projector works well with your computer, please make sure the timing of the display mode is compatible with the projector.
Note: Functions vary depending on model definition.
Note: USB cable needs powered extender if the length is over 5 m.
Note: Some smartphones require a converter (supplied by smartphone maker) to enable the MHL function.
Note: Before connecting the projector, remove the cable management, refer to "Removing the cable management" section.
Note: DC 12V out connector support 12V/100mA power for screen control only.
Note: USB DC 5V out connector support 5V/1.5A power output for power bank charging only when MHL source is not detected.

Downloaded from www.Manualslib.com manuals search engine

English

Turning the Projector On/Off

Turning on the Projector

1 Ensure that the power cord and signal cable are securely connected. The Power indicator LED will flash red.

2 Turn on the projector by pressing "**Power**" button on the control panel or remote control, and the Power indicator LED will turn blue.

3 Turn on your source (computer, notebook, video player ,etc.). The projector will detect your source automatically.

- If the screen displays "Lock" and "Source" icons, it means the projector is locked onto a specific source type and there is no such type of input signal detected.
- If the screen displays "No Signal", please make sure the signal cables are securely connected.
- If you connect to multiple sources at the same time, use the "Source" button on either control panel or the remote control or direct source key on the remote control to switch between inputs.



Downloaded from www.Manualslib.com manuals search engine

Turning the projector off

1 To turn the projector off, press and hold the power button. This message appears: **"Please press the power button again to complete the shutdown process."** Press the power button again.

2 The LED power indicator will turn RED and blink rapidly after the projector is turned off, and the fan(s) will continue to operate for about 2 minutes to ensure that the system cools properly. (only supported under "Instant Resume" mode)

3 As long as the power cord remains plugged in, you can press the power button to turn the projector immediately back on anytime during the 2-minute shutdown process. (only supported under "Instant Resume" mode)

4 Once the system has finished cooling, the LED power indicator will stop blinking and turn solid red to indicate standby mode.

5 It is now safe to unplug the power cord.

Warning indicators:

- **"Projector Overheated. Lamp will automatically turn off soon."**
  This onscreen message indicates that the projector has overheated. The lamp with automatically turn off, the projector will automatically shut down, and the LED temp indicator will turn solid red. Contact your local dealer or service center.
- **"Fan failed. Lamp will automatically turn off soon."**
  This onscreen message indicates that the fan has failed. The lamp will automatically turn off, the projector will automatically shut down, and the LED temp indicator will blink. Contact your local dealer or service center.

Note: Whenever the projector automatically shuts down and the LED lamp indicator turns solid red, contact your local reseller or service center.
Note: Functions vary depending on model definition.
Attention! The projector will enter a two minute cool down period to ensure continued optimal lamp operation.

Downloaded from www.Manualslib.com manuals search engine

English

Adjusting the Projected Image

Adjusting the Height of Projected Image

The projector is equipped with elevator feet for adjusting the height of image.

To raise/lower the image:

Use Tilt adjusting wheel to fine-tune the display angle.



Downloaded from www.Manualslib.com manuals search engine

How to optimize image size and distance

Consult the table below to find the optimal image sizes achievable when the projector is positioned at a desired distance from the screen.

- XGA series

If the projector is 2.0 m from the screen, good image quality is possible for image sizes between 52" and 70".

Note: Remind as below figure, the space of 123 cm height is required when located at 2 m distance.



Desired Distance (m) <A>	Screen size (Min zoom)		Top	Screen size (Max zoom)		Top
	Diagonal (inch) <B>	W (cm) x H (cm)	From base to top of image (cm) <C>	Diagonal (inch) <B>	W (cm) x H (cm)	From base to top of image (cm) <C>
1.0	26	52 x 39	45	35	71 x 53	61
1.5	39	79 x 59	68	53	107 x 80	92
2.0	52	105 x 79	91	70	143 x 107	123
2.5	65	131 x 98	113	88	178 x 134	154
3.0	78	157 x 118	136	105	214 x 160	184
3.5	90	184 x 138	158	123	249 x 187	215
4.0	103	210 x 157	181	140	285 x 214	246
4.5	116	236 x 177	204	158	321 x 241	277
5.0	129	262 x 197	226	175	356 x 267	307
6.0	155	315 x 236	272	210	428 x 321	369
7.0	181	367 x 276	317	246	499 x 374	430
8.0	207	420 x 315	362	281	570 x 428	492
8.6	222	451 x 339	389	302	613 x 460	529

Zoom Ratio: 1.36x

Downloaded from www.Manualslib.com manuals search engine

- 1080p series

If the projector is 3 m from the screen, good image quality is possible for image sizes between 60" and 96".

Note: Remind as below figure, the space of 139 cm height is required when located at 3 m distance.



Desired Distance (m) <A>	Screen size (Min zoom)		Top	5creen size (Max zoom)		Top
	Diagonal (inch) <8>	W (cm) x H (cm)	From base to top of image (cm) <C>	Diagonal (inch) <8>	W (cm) x H (cm)	From base to top of image (cm) <C>
1.0	20	45 x 25	29	32	71 x 40	46
1.5	30	67 x 38	44	48	106 x 60	69
2.0	40	89 x 50	58	64	142 x 80	93
2.5	50	112 x 63	73	80	177 x 100	116
3.0	60	134 x 75	87	96	213 x 120	139
3.5	71	156 x 88	102	112	248 x 140	162
4.0	81	179 x 100	117	128	284 x 160	185
5.0	101	223 x 126	146	160	355 x 199	231
6.0	121	268 x 151	175	192	426 x 239	278
7.0	141	313 x 176	204	224	496 x 279	324
8.0	161	357 x 201	233	256	567 x 319	370
9.0	181	402 x 226	262	288	638 x 359	416
9.4	190	420 x 236	274	301	667 x 375	435

Zoom Ratio: 1.59x

Downloaded from www.Manualslib.com manuals search engine

- WUXGA series

If the projector is 3.0 m from the screen, good image quality is possible for image sizes between 62" and 99".

Note: Remind as below figure, the space of 142 cm height is required when located at 3.0 m distance.



Desired Distance (m) <A>	Screen size (Min zoom)		Top	Screen size (Max zoom)		Top
	Diagonal (inch) <B>	W (cm) x H (cm)	From base to top of image (cm) <C>	Diagonal (inch) <B>	W (cm) x H (cm)	From base to top of image (cm) <C>
1.0	21	45 x 28	30	33	71 x 44	47
1.5	31	67 x 42	45	49	106 x 66	71
2.0	41	89 x 56	60	66	142 x 89	95
2.5	52	112 x 70	75	82	177 x 111	119
3.0	62	134 x 84	90	99	213 x 133	142
3.5	73	156 x 98	104	115	248 x 155	166
4.0	83	179 x 112	119	132	284 x 177	190
5.0	104	223 x 140	149	165	355 x 222	237
6.0	124	268 x 167	179	198	426 x 266	285
7.0	145	313 x 195	209	230	496 x 310	332
8.0	166	357 x 223	239	263	567 x 355	379
9.0	187	402 x 251	269	296	638 x 399	427
9.2	191	411 x 257	275	303	652 x 408	436

Zoom Ratio: 1.59x

Downloaded from www.Manualslib.com manuals search engine

English

How to get a preferred image size by adjusting distance and zoom

The table below shows how to achieve a desired image size by adjusting either the position or the zoom ring.

- XGA series

To obtain an image size of 50" set the projector at a distance 1.4 m and 1.9 m from the screen.



Desired Image Size		Distance (m)		Top (cm)
Diagonal (inch) <A>	W (cm) x H (cm)	Max zoom <8>	Min zoom <C>	From base to top of image <D>
20	53 x 40		1.0	46
40	81 x 61	1.1	1.5	70
50	102 x 76	1.4	1.9	88
60	122 x 91	1.7	2.3	105
70	142 x 107	2.0	2.7	123
80	163 x 122	2.3	3.1	140
90	183 x 137	2.6	3.5	158
100	203 x 152	2.9	3.9	175
120	244 x 183	3.4	4.6	210
150	305 x 229	4.3	5.8	263
180	366 x 274	5.1	7.0	315
200	406 x 305	5.7	7.7	351
250	508 x 381	7.1	9.7	438
300	610 x 457	8.6		526

Zoom Ratio: 1.36x

Downloaded from www.Manualslib.com manuals search engine

- 1080p series

To obtain an image size of 60" set the projector at a distance 1.9 m and 3.0 m from the screen.



Desired Image Size		Distance (m)		Top (cm)
Diagonal (inch) <A>	W (cm) x H (cm)	Max zoom <B>	Min zoom <C>	From base to top of image <D>
20	44 x 25		1.0	29
40	89 x 50	1.2	2.0	58
50	111 x 62	1.6	2.5	72
60	133 x 75	1.9	3.0	87
70	155 x 87	2.2	3.5	101
80	177 x 100	2.5	4.0	116
90	199 x 112	2.8	4.5	130
100	221 x 125	3.1	5.0	144
120	266 x 149	3.7	6.0	173
150	332 x 187	4.7	7.4	217
180	398 x 224	5.6	8.9	260
200	443 x 249	6.2	9.9	289
250	553 x 311	7.8	12.4	361
300	664 x 374	9.4		433

Zoom Ratio: 1.59x

Downloaded from www.Manualslib.com manuals search engine

English

- WUXGA series

To obtain an image size of 60" set the projector at a distance 1.8 m and 2.9 m from the screen.



Desired Image Size		Distance (m)		Top (cm)
Diagonal (inch) <A>	W (cm) x H (cm)	Max zoom <8>	Min zoom <C>	From base to top of image <D>
20	43 x 27		1.0	29
40	86 x 54	1.2	1.9	58
50	108 x 67	1.5	2.4	72
60	129 x 81	1.8	2.9	86
70	151 x 94	2.1	3.4	101
80	172 x 108	2.4	3.9	115
90	194 x 121	2.7	4.3	130
100	215 x 135	3.0	4.8	144
120	258 x 162	3.6	5.8	173
150	323 x 202	4.6	7.2	216
180	388 x 242	5.5	8.7	259
200	431 x 269	6.1	9.6	288
250	538 x 337	7.6	12.1	360
300	646 x 404	9.1		432

Zoom Ratio: 1.59x

Downloaded from www.Manualslib.com manuals search engine

How to get a preferred image position by adjusting lens shift

The projector is equipped with lens shift for adjusting the position of projected image up and down without requiring you to physically move the projector.



Note: The figures shown in this section are for reference only not approximate value. The figures between units can be different due to assembly tolerance.

Downloaded from www.Manualslib.com manuals search engine

English

The vertical image height can be adjusted between -6% and 21% of the image height. (The minimum vertical image offset is fixed at 5% of the image height above the centre of the projector lens.)



Downloaded from www.Manualslib.com manuals search engine

User Controls

Installation menu

The installation menu provides an onscreen display (OSD) for projector installation and maintenance. Use the OSD only when the message "No signal input" is displayed on the screen.

The menu options include settings and adjustments for screen size and distance, focus, keystone correction and more .

1 Turn on the projector by pressing "**Power**" button on the control pad.

2 Press the "**MENU**" button on the remote control to launch the OSD for projector installation and maintenance.

3 The background pattern acts as a guide to adjusting the calibration and alignment settings, such as screen size and distance, focus and more .

4 The Installation menu includes the following options:

- •Projection method
- •Projection Mode
- •Projection Location
- •Auto Keystone settings
- •Manual Keystone settings
- •H. Keystone
- •V. Keystone
- •LAN/WiFi
- •LAN
- •LAN IP/Mask
- •Wireless HD dongle settings
- •Language settings
- •DC 5V Out (Standby)

Downloaded from www.Manualslib.com manuals search engine

•Reset to factory default function

Use the up and down arrow keys to select an option, the left and right arrow keys to adjust selected option settings, and the right arrow key to enter a submenu for feature setting. The new settings will be saved automatically upon exiting the menu.

5 Push the MENU button anytime to exit the menu and return to the Acer welcome screen.

Note: Functions vary depending on model definition.

Downloaded from www.Manualslib.com manuals search engine

Onscreen Display (OSD) Menus

The projector has multilingual OSD that allow you to make image adjustments and change a variety of settings.

Using the OSD menus

- To open the OSD menu, press "MENU" on the remote control or control panel.
- When the OSD is displayed, use the ▲▼ keys to select any item in the main menu. After selecting the desired main menu item, press ▶ to enter submenu for feature setting.
- Use the ▲▼ keys to select the desired item and adjust the settings by using the ◀▶ keys.
- Select the next item to be adjusted in the submenu and adjust as described above.
- Press "MENU" on the remote control or control panel, the screen will return to the main menu.
- To exit OSD, press "MENU" on the remote control or control panel. The OSD menu will close and the projector will automatically save the new settings.



Note: Some of the following OSD settings may not be available. Please refer to the actual OSD of your projector.
Note: Functions vary depending on model definition.

Downloaded from www.Manualslib.com manuals search engine

English

Color

LumiSense+	The light sensor of LumiSense+ technology can intelligently optimize the brightness and color saturation of projected image based on actual ambient light. The feature greatly enhances dark detail visibility and color saturation. • Off: For normal mode. (ambient light sensor is off) • Auto Bright: Light sensor is on to automatically detect ambient light and optimize the brightness and color saturation of projected image. • Dynamic Black: automatically optimize the display of dark movie scenes enabling them to be shown in incredible detail.
Display Mode	There are many factory presets optimized for various types of images. • Bright: For brightness optimization. • Presentation: For meeting presentation. • Standard: For common environment. • Video: For playing video in a bright environment. • Game: For game content. • Education: For education environment. • Movie: For brighter and general movie/video/photo playing. • Dark Cinema: For dark movie content. • Sport: For sport picture. • User: Memorize user's settings.
Wall color	Use this function to choose a proper color according to the wall. There are several choices, including white, light yellow, light blue, pink, dark green. It will compensate the color deviation due to the wall color to show the correct image tone.
Brightness	Adjust the brightness of the image. • Press ◀ to darken the image. • Press ▶ to lighten the image.
Contrast	"Contrast" controls the difference between the lightest and darkest parts of the picture. Adjusting the contrast changes the amount of black and white in the image. • Press ◀ to decrease the contrast. • Press ▶ to increase the contrast.
Saturation	Adjusts a video image from black and white to fully saturated color. • Press ◀ to decrease the amount of color in the image. • Press ▶ to increase the amount of color in the image.

Downloaded from www.Manualslib.com manuals search engine

Tint	Adjusts the color balance of red and green. • Press ◀ to increase the amount of green in the image. • Press ▶ to increase the amount of red in the image.
Color Temperature	Mode Use this function to choose CT1, CT2 (Native), CT3, User mode.
	R Gain Adjusts the red gain for color temperature optimization.
	G Gain Adjusts the green gain for color temperature optimization.
	B Gain Adjusts the blue gain for color temperature optimization.
	R Bias Adjusts the red bias for color temperature optimization.
	G Bias Adjusts the green bias for color temperature optimization.
	B Bias Adjusts the blue bias for color temperature optimization.
Gamma	Effects the representation of dark scenery. With greater gamma value, dark scenery looks brighter.

Note: "Saturation" and "Tint" functions are not supported under computer or HDMI mode.

Note: Functions vary depending on model definition.

Downloaded from www.Manualslib.com manuals search engine

English

Image

Projection Mode	• Front-Desktop. The factory default setting. • Rear-Desktop. When you select this function, the projector reverses the image so you can project from behind a translucent screen. • Rear-Ceiling. When you select this function, the projector reverses and inverts the image at same time. You can project from behind a translucent screen with ceiling mounted projection. • Front-Ceiling. When you select this function, the projector inverts the image for ceiling-mounted projection.
Aspect Ratio	Use this function to choose your desired aspect ratio. • Auto. Keep the image with original width-higth ratio and maximize the image to fit native horizontal or vertical pixels. • Full. Resize image to fit full screen by width (1280 pixels) and height (800 pixels). • 4:3. The image will be scaled to fit the screen and displayed using a 4:3 ratio. • 16:9. The image will be scaled to fit the width of the screen and the height adjusted to display the image using a 16:9 ratio. • L.Box. Keep original signal aspect ratio and zoom in by 1.333 times.
H/V. Keystone	Auto V. Keystone Automatically adjusts vertical image.
	H. Keystone Press the ◀ or ▶ button to adjust image distortion horizontally and makes a squarer image.
	V. Keystone Press the ◀ or ▶ button to adjust image distortion vertically and makes a squarer image.
4 Corner Correction	Manually adjusts the shape and size of an image that is unevenly rectangular on all sides. Press "MODE" repeatedly to select the corner that you wish to adjust. Press four directional selection keys to adjust the image shape.  <Note> The function is unavailable when H./V. Keystone is adjusted.
Sharpness	Adjusts the sharpness of the image. • Press ◀ to decrease the sharpness. • Press ▶ to increase the sharpness.

Downloaded from www.Manualslib.com manuals search engine

H. Position (Horizontal position)	• Press ◀ to move the image left. • Press ▶ to move the image right.
V. Position (Vertical position)	• Press ◀ to move the image down. • Press ▶ to move the image up.
Frequency	"Frequency" changes the projector's refresh rate to match the frequency of your computer's graphics card. If you can see a vertical flickering bar in the projected image, use this function to make the necessary adjustments.
Tracking	Synchronizes the signal timing of the projector with the graphics card. If you experience an unstable or flickering image, use this function to correct it.
HDMI Color Range	Adjust the color range of the HDMI image data to correct color display error. • Auto: Automatically adjust by information from player. • Limited Range: Prosess the input image as limited color range data. • Full Range: Prosess the input image as full color range data.
HDMI Scan Info	Adjust the overscan ratio of the HDMI image on screen. • Auto: Automatically adjust by information from player. • Underscan: Always no overscan on HDMI image. • Overscan: Always keep overscan on HDMI image.

Note: "H. Position", "V. Position", "Frequency" and "Tracking" functions are not supported under HDMI or Video mode.
Note: "HDMI Color Range" and "HDMI Scan Info" functions are only supported under HDMI mode.
Note: Functions vary depending on model definition.

Downloaded from www.Manualslib.com manuals search engine

English

Setting

Startup Screen	Use this function to select your desired startup screen. If you change the setting, the changes will take effect when you exit the OSD menu. • Acer: The default startup screen of your Acer projector. • User: Use memorize picture from "Screen Capture" function.
Screen Capture	Use this function to customize the startup screen. To capture the image that you want to use as the startup screen, follow the instructions below. Notice: Before proceeding with the following steps, make sure that the "Keystone" is set to the default value 0 and the aspect ratio is set to 4:3. For details, refer to the "Image" section. • Change the "Startup Screen" from the default setting "Acer" to "User". • Press "Screen Capture" to customize the startup screen. • A dialog box appears to confirm the action. Choose "Yes" to use the current image as your customized startup screen. The capture range is the red rectangular area. Choose "No" to cancel the screen capture and exit the onscreen display (OSD). • A message appears, stating that the screen capture is in progress. • When the screen capture is finished, the message disappears and the original display is shown. • The customized startup screen, as shown below, takes effect when there is a new input signal or when you restart the projector.
Source Lock	When Source Lock is turned "Off", the projector will search for other signals if the current input signal is lost. When Source Lock is turned "On", it will "lock" the current source channel unless you press "Source" button on the remote control for the next channel.
Closed Caption	Selects a preferred closed captioning mode from CC1, CC2, CC3, CC4, (CC1 displays captions in the primary language in your area). Select "Off" to turn off the captioning feature. This function is only available when a composite video or S-Video input signal is selected and its system format is NTSC. <Note> Set your screen aspect ratio to 4:3. This function is not available when the aspect ratio is "16:9" or "Auto" .
Auto Screen	Default is "On", the down/up move of electronic screen will be related with power on/off of the projector.
VGA OUT (Standby)	Default is "Off". Choose "On" to enable VGA OUT connection.
DC 5V Out (Standby)	Default is "Off". Choose "On" to enable DV 5V OUT connection during standby mode.
HDMI CEC	Default is "Off". Select "On" to enable HDMI CEC function.
Reset	• Press the ▶ button and choose "Yes" to return the parameters on all menus to the factory default settings.

Downloaded from www.Manualslib.com manuals search engine

Security	**Security** This projector provides a useful security function for the administrator to manage usage of the projector . Press ▶ to change the "Security" setting. If the security function is enabled, your must enter the "Administrator Password" first before changing the security settings. • Select "On" to enable the security function. The user has to enter a password to operate the projector. Please refer to the "User Password" section for details. • If "Off" is selected, then the user can turn on the projector without password.
	Timeout(Min.) Once "Security" is activated to "On", the administrator can set timeout function. • Press ◀ or ▶ to select the timeout interval. • The range is from 10 minute to 990 minutes. • When the time is up, the projector will prompt the user to enter the password again. • The factory default setting of "Timeout(Min.)" is "Off". • Once the security function is enabled, the projector will request user to enter password when switch on the projector . Both "User Password" and "Administrator Password" can be accepted for this dialogue.
	User Password • Press ▶ to setup or change the "User Password". • Press number keys to set your password on the remote control and press "MENU" to confirm. • Press ◀ to delete character. • Enter the password when you see "Confirm Password" displayed. • The password should be between 4 and 8 characters long. • If you select "Request password only when plugging the power cord in.", the projector will prompt the user to enter the password every time the power cord is plugged. • If you select "Always request password while projector turns on.", the user has to enter the password every time when the projector is turned on.
	Administrator Password The "Administrator Password" can be used in both the "Enter Administrator Password" and "Enter Password" dialog boxes. • Press ▶ to change the "Administrator Password". • The factory default of "Administrator Password" is "1234". If you forgot your administrator password, do the following to retrieve the administrator password. • An unique 6-digit "Universal Password" which is printed on the Security Card (please check accessory in the box). This unique password is the number which will be accepted by projector anytime no matter what the Administrator Password is. • If losing this security card and number, please contact with an Acer service center.

Downloaded from www.Manualslib.com manuals search engine

	Lock to user startup screen Default Lock User Startup Screen is "Off". If lock user startup screen is "On", users cannot change startup screen anymore and avoid other users change that arbitrarily. Choose "Off" to unlock startup screen.
LAN	**LAN** Default is "Off". Choose "On" to enable LAN connection <Note> If users want to do LAN control under standby mode, change VGA OUT (Standby) from Off to On.
	LAN IP/Mask Identify IP and Mask address.
	LAN Reset Reset LAN function.
	Control Channel Default is "RS232/LAN". Choose "HDBaseT" to enable HDBaseT connection
	HDBaseT IR Carrier Default is "Off", Choose "On" to enable HDBaseT IR Carrier function.

Note: Functions vary depending on model definition

Management

ECO Mode	Choose "On" to dim the projector lamp which will lower power consumption, extend the lamp life and reduce noise. Choose "Off" to return normal mode.
High Altitude	Choose "On" to turn on High Altitude mode. Operate the fans at full speed continuously to allow for proper high altitude cooling of the projector.
Turn Off Mode	• Instant Off: Shuts down the projector without fan cooling. • Instant Resume: Resumes the system when the Power button is pressed again within 2 minutes.
Auto Shutdown	The projector will automatically shutdown when there is no signal input after the allocated time. (default is 120 minutes)
AC Power On	Choose "On" to power on projector while AC power plug in.
Lamp Hour Elapse	Displays the lamp's elapsed operating time (in hours).
Lamp Reminding	Activate this function to display a reminder to change the lamp 30 hours before its expected end-of-life.
Lamp Hour Reset	Press the ▶ button and choose "Yes" to turn the lamp hour counter to 0 hours.

Note: Functions vary depending on model definition

Downloaded from www.Manualslib.com manuals search engine

Audio

Volume	• Press ◀ to decrease the volume. • Press ▶ to increase the volume.
MIC Volume	Adjust the volume from "MIC IN" connector.
Mute	• Choose "On" to mute the volume • Choose "Off" to restore the volume.
Power On/Off Volume	Select this function to adjust the notification volume when turning the projector on/off.
Alarm Volume	Select the function to adjust the volume of any warning notifications.

Note: Functions vary depending on model definition.

Downloaded from www.Manualslib.com manuals search engine

3D

3D	Choose "On" to enable DLP 3D function. • On: Choose this item while using DLP 3D glasses, 120Hz 3D capable graphics cards and HQFS format file or DVD with corresponding SW player. • Off: Turn off 3D mode.
3D Format	If the 3D content is not displayed correctly, you can select a 3D format that suits the 3D content you are viewing and obtain the best result
24P 3D	Choose "96Hz" or "144Hz" to compatible with 3D glasses.
3D L/R Invert	If you see a discrete or overlapping image while wearing DLP 3D glasses, you may need to execute "Invert" to get best match of left/right image sequence to get the correct image (for DLP 3D).
3D Warning Message	Choose "On" to display the 3D warning message. 

Note: It needs correct settings on graphic card 3D application program for correct 3D display.
Note: The SW players, such as Stereoscopic Player and DDD TriDef Media Player can support 3D format files. You can download these three players on web page below,
- Stereoscopic Player (Trial)
  http://www.3dtv.at/Downloads/Index_en.aspx
- DDD TriDef Media Player (Trial)
  http://www.tridef.com/download/TriDef-3-D-Experience-4.0.2.html

Note: "3D L/R Invert" is only available when 3D is enabled.
Note: There has reminder screen if 3D still enable when power on projector. Please adjust setting depended on your purpose.

Language

Language	Choose the multilingual OSD menu. Use the ▲ or ▼ key to select your preferred menu language. • Press ▶ to confirm the selection.

Downloaded from www.Manualslib.com manuals search engine

Acer LAN webpage management

How to login in

Open browser and enter the Server IP address by 192.168.100.10 to find below homepage of acer LAN webpage management. A password is needed to login in before using.

Select a user. **Administrator** is with high authority that can process more operations such as network setting and alert setting. Default password of administrator is "admin". And **User** is with normal authority with default password by "user". Click Login button to enter into homepage with correct password.

Downloaded from www.Manualslib.com manuals search engine

English

Home

Home page shows connection status and you can find three main functions listed, **Control Panel**, **Networking Setting** and **Alert Setting**.



Note: Control Panel and Networking Setting are only for Administrator account.

Control Panel

Enduser can control and adjust projector setting value via this page.

Downloaded from www.Manualslib.com manuals search engine

Network Setting

Enduser can set IP address, group name and password as wish. After change network configurations or password, projector will reboot automatically after press "Apply".

Note: Group Name and projector Name must be less then 32 characters

Alert Setting

Enduser can send mail with error message right away if projector has problem.

Downloaded from www.Manualslib.com manuals search engine

English

Logout

After tap Logout, you will return to login page within 5 seconds.



Note: Functions vary depending on model definition.

Downloaded from www.Manualslib.com manuals search engine

Appendices

Troubleshooting

If you experience a problem with your Acer projector, refer to the following troubleshooting guide. If the problem persists, please contact your local reseller or service center.

Image Problems and Solutions

#	Problem	Solution
1	No image appears onscreen	• Connected as described in the "Getting Started" section. • Ensure none of the connector pins are bent or broken. • Check if the projector lamp has been securely installed. Please refer to the "Replacing the Lamp" section. • Make sure you have removed the lens cap and the projector is switched on.

2	Partial, scrolling or incorrectly displayed image (for PC (Windows 2000/XP/Vista/ Windows 7/ Windows 8))	• Press "RESYNC" on the control panel
		• For an incorrectly displayed image
		  • Open "My Computer", open the "Control Panel", and then double-click the "Display" icon.
		  • Select the "Settings" tab.
		  • Verify that your display resolution setting is lower than or equal to WUXGA-RB (1920 x 1200).
		  • Click the "Advanced Properties" button.
		If the problem still appears, change the monitor display you are using and follow the steps below.
		  • Verify that the resolution setting is lower than or equal to WUXGA-RB (1920 x 1200).
		  • Click the "Change" button under the "Monitor" tab.
		  • Click "Show all devices". Next, select "Standard monitor types" under the SP box, and choose the resolution mode you need under the "Models" box.
		  • Verify that the resolution setting of the monitor display is lower than or equal to WUXGA-RB (1920 x 1200).

Downloaded from www.Manualslib.com manuals search engine

English

3	Partial, scrolling or incorrectly displayed image (For notebooks)	• Press "RESYNC" on the control panel
		• For an incorrectly displayed image
		  • Follow the steps for item 2 (above) to adjust the resolution of your computer.
		  • Press the toggle output settings. Example [Fn]+[F4], Compaq [Fn]+[F4], Dell [Fn]+[F8], Gateway [Fn]+[F4], IBM [Fn]+[F7], HP [Fn]+[F4], NEC [Fn]+[F3], Toshiba [Fn]+[F5]
		• If you experience difficulty changing resolutions or your monitor freezes, restart all equipment including the projector.

4	The screen of the notebook computer is not displaying your presentation	• If you are using a Microsoft® Windows® based notebook. Some notebook PCs may deactivate their own screens when a second display device is in use. Each has a different way to be reactivated. Refer to your computer's manual for detailed information. • If you are using an Apple® Mac® OS based notebook. In System Preferences, open Display and select Video Mirroring "On".
5	Image is unstable or flickering	• Adjust the "Tracking" to correct it. Refer to the "Image" section for more information. • Change the display color depth settings on your computer.
6	Image has vertical flickering bar	• Use "Frequency" to make an adjustment. Refer to the "Image" section for more information. • Check and reconfigure the display mode of your graphics card to make it compatible with the projector.
7	Image is out of focus	• Make sure the lens cap is removed. • Adjusts the focus ring on the projector lens. • Make sure the projection screen is within the required distance of 3.3 to 28.1 feet (1.0 to 8.6 meters) (XGA series) / 3.3 to 30.7 feet (1.0 to 9.4 meters) (1080p series) / 3.3 to 29.9 feet (1.0 to 9.1 meters) (WUXGA series) from the projector. Refer to the "How to get a preferred image size by adjusting distance and zoom" section for more information.

Downloaded from www.Manualslib.com manuals search engine

8	Image is stretched when displaying a "widescreen" DVD title	When you play a DVD encoded in anamorphic or 16 9 aspect ratio you may need to adjust the following settings. • If you play a 4 3 format DVD title, please change the format to 4 3 in the projector OSD. • If the image is still stretched, you will also need to adjust the aspect ratio. Set up the display format to 16 9 (wide) aspect ratio on your DVD player. • If you play an Letterbox (LBX) format DVD title, please change the format to Letterbox (LBX) in the projector OSD.
9	Image is too small or too large	• Adjust the zoom lever on the top of the projector. • Move the projector closer to or further from the screen. • Press "MENU" on the remote control. Go to "Image -> Aspect Ratio" and try different settings or press "RATIO" on the remote control to adjust directly.
10	Image has slanted sides	• If possible, reposition the projector so that it is centered on the screen. • Press the "Keystone ⏢ / ⏢" button on the remote control until the sides are vertical.
11	Image is reversed	• Select "Image --> Projection Mode" on the OSD and adjust the projection direction.

Downloaded from www.Manualslib.com manuals search engine

English

OSD Messages

#	Condition	Message Reminder
1	Message	• Fan Fail - the system fan is not working  • Projector Overheated - the projector has exceeded its recommended operating temperature and must be allowed to cool down before it may be used. Please check the following message  Please also check the dust filters if they are installed. If the dust filter is clogged with dust, please clean it. Please refer to "Cleaning and replacing the dust filters" for details. • Replace the lamp - the lamp is about to reach its maximum lifetime. Prepare to replace it soon. 

Problems with the Projector

#	Condition	Solution
1	The projector stops responding to all controls	If possible, turn off the projector, then unplug the power cord and wait at least 30 seconds before reconnecting power.
2	Lamp burns out or makes a popping sound	When the lamp reaches the end of its useful life, it will burn out and may make a loud popping sound. If this happens, the projector will not turn on until the lamp module has been replaced. To replace the lamp, follow the procedures in the "Replacing the Lamp" section.

Downloaded from www.Manualslib.com manuals search engine

LED & Alarm Definition Listing

LED Messages

Message	Lamp_LED	Temp_LED	Power LED	
	Red	Red	Red	Blue
Input power plug	Flash ON to OFF 100ms	Flash ON to OFF 100ms	Flash ON to OFF 100ms	--
Standby	--	--	ON	--
Power button ON	--	--	--	ON
Lamp retry	--	--	--	Quick Flashing
Power off (Cooling state)	--	--	Quick Flashing	--
Power button OFF (cooling completed; standby mode)	--	--	ON	--
Error (thermal failure)	--	ON	--	ON
Error (fan lock)	--	Quick Flashing	--	ON
Error (lamp breakdown)	ON	--	--	ON
Error (color wheel fail)	Quick Flashing	--	--	ON

Downloaded from www.Manualslib.com manuals search engine

English

How to install cable management



I. Ceiling Mount 5cenario

1 Plug in power cord and other cables you need.
2 Install two support base and tighten the screws.(Illustration #1,2,3,4)
3 Push the cable management. (Illustration #5)
4 If you need to install Acer Dongle (WirlessHD-Kit/WirelessAndroid-Kit/WirelessCA5T), follow the below steps:
   (A) Use a screwdriver to remove the screw from the cover.
   (B) Push up the cover.
   (C) Remove the cover.
   (D) Connect dongle to HDMI extension cable port; Connect to HDMI port on projector.
5 Disassembly the cable management cover firmly to projector, and tighten the screw. (Illustration #5,4,3,2,1)



Downloaded from www.Manualslib.com manuals search engine

Cleaning and replacing the dust filters

Cleaning the dust filters

Clean the dust filters after every 1000 hours of use. If they are note cleaned periodically, they can become clogged with dust, preventing proper ventilation. This can cause overheating and damage the projector.



Follow these steps:

1 Turn the projector off. Wait for the Power LED to stop flashing then unplug the power cord.
2 Allow the projector at least 30 mins to cool down.
3 Pull out the dust filter. (Illustration #1, #2)
4 To clean the dust filters, use a small vacuum cleaner designed for computers and other office equipment. (Illustration #3)
5 If the dirt is difficult to remove or the filter is broken, please contact your local dealer or service center to obtain a new filter.

Downloaded from www.Manualslib.com manuals search engine

English

Replacing the Lamp

Use a screwdriver to remove the screw(s) from the cover, and then pull out the lamp.

The projector will detect the lamp life. You will be shown a warning message **"Lamp is approaching the end of its useful life in full power operation. Replacement suggested!"** When you see this message, change the lamp as soon as possible. Make sure the projector has been cooling down for at least 30 minutes before changing the lamp.

Warning: The lamp compartment is hot! Allow it to cool down before changing the lamp.



To Change the Lamp

Turn off the projector by pressing the Power button.

Allow the projector at least 30 minutes to cool down.

Disconnect the power cord.

1 Use a screwdriver to remove the screw from the cover. (Illustration #1)
Push up and remove the cover. (Illustration #2)

2 Remove the screw that secure the lamp module. (Illustration #3)
Lift the handle so that it stands up. (Illustration #4)
Pull out the lamp plug. (Illustration #5)

3 Lift the handle so that it stands up. Pull out the lamp module by force. (Illustration #6)

To replace the lamp module, use a new lamp and reverse the above steps.

Downloaded from www.Manualslib.com manuals search engine

Warning: To reduce the risk of personal injury, do not drop the lamp module or touch the lamp bulb. The bulb may shatter and cause injury if it is dropped.

Downloaded from www.Manualslib.com manuals search engine

English

Ceiling Mount Installation

If you wish to install the projector using a ceiling mount, please refer to the steps below:

1 Drill four holes into a solid, structural ceiling member, and secure the ceiling mount base to the ceiling.





2 Choose the length combination based on actual environment. (CM-01S doesn't include Type 2 and Type 3.)



Downloaded from www.Manualslib.com manuals search engine

3 Type 1:
For the standard size use three bracket screws to mount the projector to the ceiling mount bracket.
Type 2 and Type 3:
Alternatively, for the larger size, use the sliding extensions for more supports.



Note: It is recommended that you keep a reasonable space between the bracket and the projector to allow for proper heat distribution.

4 Connect the main body connector to the projector bracket (illustration 1), and then screw up four screws (illustration 2).



Illustration 1 Illustration 2

Downloaded from www.Manualslib.com manuals search engine

English

5 Adjust the angle and positioning as necessary.



Screw Type B		Washer Type	
Diameter (mm)	Length (mm)	Large	Small
4	25	V	V



Downloaded from www.Manualslib.com manuals search engine

Specifications

The specifications listed below are subject to change without notice. For final specs, please refer to Acer's published marketing specifications.

Projection system	DLP®
Resolution	• P6200/F211/PM-X01/P6200S/F211S/PM-X01S series Native 1024 x 768 XGA resolution • P6S00/F2S1/PM-801 series 1920x1080 1080p resolution • P6600/F261/PM-WU01 series True 1920x1200 WUXGA resolution • Maximum UXGA (1600 x 1200), WSXGA+ (1680x10S0), 1080p(1920x1080), WUXGA-R8 (1920 x 1200)
Computer compatibility	I8M PC and compatibles, Apple Macintosh, iMac and VESA standards SXGA, XGA, VGA, SVGA, SXGA+, WXGA, WXGA+, WSXGA +
Video compatibility	NTSC (3.S8/4.43), PAL (8/D/G/H/I/M/N), SECAM (8/D/G/K/K1/L), HDTV (720p, 1080i, 1080p), EDTV (480p, S76p), SDTV (480i, S76i)
Aspect ratio	Full, 4:3, 16:9, L.8ox
Displayable colors	16.7 million colors
Projection lens	• P6200/F211/PM-X01/P6200S/F211S/PM-X01S series F = 2.S ~ 2.93, f = 1S.98mm ~ 21.42mm, 1:1.36 Manual Zoom and Manual Focus • P6S00/F2S1/PM-801/P6600/F261/PM-WU01 series F = 2.S ~ 3.26, f = 20.91mm ~ 32.63mm, 1:1.S9 Manual Zoom and Manual Focus
Projection screen size (diagonal)	• P6200/F211/PM-X01/P6200S/F211S/PM-X01S series 26" (66cm) ~ 300" (762cm) • P6S00/F2S1/PM-801 series 20" (S1cm) ~ 300" (762cm) • P6600/F261/PM-WU01 series 21" (S3cm) ~ 300" (762cm)
Projection distance	• P6200/F211/PM-X01/P6200S/F211S/PM-X01S series 3.3' (1.0m) ~ 28.1' (8.6m) • P6S00/F2S1/PM-801 series 3.3' (1.0m) ~ 30.7' (9.4m) • P6600/F261/PM-WU01 series 3.3' (1.0m) ~ 29.9' (9.1m)
Throw ratio	• P6200/F211/PM-X01/P6200S/F211S/PM-X01S series 70"@2m (1.40 ~ 1.91:1) • P6S00/F2S1/PM-801 series 64"@2m (1.41 ~ 2.24:1) • P6600/F261/PM-WU01 series 66"@2m (1.41 ~ 2.24:1)
Horizontal scan rate	1S - 100 kHz
Vertical refresh scan rate	24 - 120 Hz
Lamp type	• P6200/F211/PM-X01/P6200S/F211S/PM-X01S series 310 W user-replaceable lamp • P6S00/F2S1/PM-801/P6600/F261/PM-WU01 series 36S W user-replaceable lamp
Keystone correction	±30 degrees

Downloaded from www.Manualslib.com manuals search engine

English

Audio	Internal speaker with 10 W x 2 output
Weight	4.5 Kg (9.92 lbs)
Dimensions (W x D x H)	373 mm X 223.4 mm X 100.5 mm (14.7" x 8.8" x 4.0")
Digital Zoom	2X
Power supply	AC input 100 - 240 V auto-switching power supply
Power consumption	Normal mode 315W ± 10% @ 110VAC ECO mode 260W ± 10% @ 110VAC Standby mode < 0.5W
Operating temperature	0°C to 40°C / 32°F to 104°F
I/O connectors	• Power socket x1 • VGA input x2 • VGA output x1 • Composite input x1 • S-Video input x1 • YPbPr/YCbCr input x1 • HDMI (MHL) x1 • HDMI x1 • RS232 x1 • Mini USB x 1 (for firmware upgrade) • Audio input x1 • Microphone input x1 • Audio input (RCA) x1 • Audio output x 1 • USB DC 5V out x1 • DC 12V out x 1 • RJ45 LAN input x 1 • HDBaseT input x 1 (only for P6600/F261/PM-WU01 series)
Standard package contents	• AC power cord x1 • VGA cable x1 • Remote control x1 • Battery x2 (for remote control) (option) • User's guide (CD-ROM) x1 • Quick start guide x1 • Security card x1 • Cable management cover x1 • Dust filters x1 (option) • Carrying case x1 (option)

Note: Design and specifications are subject to change without notice.

Downloaded from www.Manualslib.com manuals search engine

Compatibility modes

A. VGA Analog

1 VGA Analog - PC Signal

Modes	Resolution	V.Frequency [Hz]	H.Frequency [KHz]
VGA	640x480	60	31.5
	640x480	72	37.9
	640x480	75	37.5
	640x480	85	43.3
	640x480	120	61.9
5VGA	800x600	56	35.1
	800x600	60	37.9
	800x600	72	48.1
	800x600	75	46.9
	800x600	85	53.7
	800x600	120	77.4
XGA	1024x768	60	48.4
	1024x768	70	56.5
	1024x768	75	60.0
	1024x768	85	68.7
	1024x768	120	99.0
5XGA	1152x864	70	63.8
	1152x864	75	67.5
	1152x864	85	77.1
	1280x1024	60	64.0
	1280x1024	72	77.0
	1280x1024	75	80.0
	1280x1024	85	91.1
QuadVGA	1280x960	60	60.0
	1280x960	75	75.2
5XGA+	1400x1050	60	65.3
UXGA	1600x1200	60	75.0
PowerBook G4	640x480	60	31.4
PowerBook G4	640x480	66.6(67)	34.9
PowerBook G4	800x600	60	37.9
PowerBook G4	1024x768	60	48.4
PowerBook G4	1152x870	75	68.7
PowerBook G4	1280x960	75	75.0
i Mac DV (G3)	1024x768	75	60.0

2 VGA Analog - Extended Wide timing

Modes	Resolution	V.Frequency [Hz]	H.Frequency [KHz]

Downloaded from www.Manualslib.com manuals search engine

WXGA	1280x768	60	47.8
	1280x768	75	60.3
	1280x768	85	68.6
	1280x720	60	44.8
	1280x720	120	92.9
	1280x800	60	49.6
	*1920x1200	60	74
	1440x900	60	59.9
W5XGA+	1680x1050	60	65.3
	1920x1080 (1080P)	60	67.5
	1366x768	60	47.7
WUXGA	*1920x1200-RB	59.94	74.04

3 VGA Analog -Component Signal

Modes	Resolution	V.Frequency [Hz]	H.Frequency [KHz]
480i	720x480(1440x480)	59.94 (29.97)	15.7
576i	720x576(1440x576)	50(25)	15.6
480p	720x480	59.94	31.5
576p	720x576	50	31.6
720p	1280x720	60	45.0
720p	1280x720	50	37.5
1080i	1920x1080	60(30)	33.8
1080i	1920x1080	50(25)	28.1
1080p	1920x1080	23.97/24	27.0
1080p	1920x1080	60	67.5
1080p	1920x1080	50	56.3

B. HDMI Digital

1 HDMI - PC Signal

Modes	Resolution	V.Frequency [Hz]	H.Frequency [KHz]
VGA	640x480	60	31.5
	640x480	72	37.9
	640x480	75	37.5
	640x480	85	43.3
	640x480	120	61.9
SVGA	800x600	56	35.1
	800x600	60	37.9
	800x600	72	48.1

Downloaded from www.Manualslib.com manuals search engine

	800x600	75	46.9
	800x600	85	53.7
	800x600	120	77.4
XGA	1024x768	60	48.4
	1024x768	70	56.5
	1024x768	75	60.0
	1024x768	85	68.7
	1024x768	120	99.0
5XGA	1152x864	70	63.8
	1152x864	75	67.5
	1152x864	85	77.1
	1280x1024	60	64.0
	1280x1024	72	77.0
	1280x1024	75	80.0
	1280x1024	85	91.1
QuadVGA	1280x960	60	60.0
	1280x960	75	75.2
5XGA+	1400x1050	60	65.3
UXGA	1600x1200	60	75.0
PowerBook G4	640x480	60	31.4
PowerBook G4	640x480	66.6(67)	34.9
PowerBook G4	800x600	60	37.9
PowerBook G4	1024x768	60	48.4
PowerBook G4	1152x870	75	68.7
PowerBook G4	1280x960	75	75.0
i Mac DV (G3)	1024x768	75	60.0

2 HDMI - Extended Wide timing

Modes	Resolution	V.Frequency [Hz]	H.Frequency [KHz]
WXGA	1280x768	60	47.8
	1280x768	75	60.3
	1280x768	85	68.6
	1280x720	60	44.8
	1280x720	120	92.9
	1280x800	60	49.6
	*1280x800-RB	119.909	101.6
	1440x900	60	59.9
	*1920x1200	60	74
W5XGA+	1680x1050	60	65.3
	1920x1080 (1080P)	60	67.5

Downloaded from www.Manualslib.com manuals search engine

	1366x768	60	47.7
WUXGA	*1920x1200-RB	59.94	74.04

3 HDMI - Video Signal

Modes	Resolution	V.Frequency [Hz]	H.Frequency [KHz]
480i	720x480(1440x480)	59.94 (29.97)	15.7
576i	720x576(1440x576)	50(25)	15.6
480p	720x480	59.94	31.5
576p	720x576	50	31.6
720p	1280x720	60	45.0
720p	1280x720	50	37.5
1080i	1920x1080	60(30)	33.8
1080i	1920x1080	50(25)	28.1
1080p	1920x1080	23.97/24	27.0
1080p	1920x1080	60	67.5
1080p	1920x1080	50	56.3
1080p	*1920x1200	59.94	74.04

4 HDMI - 1.4a 3D Timing

Modes	Resolution	V.Frequency [Hz]	H.Frequency [KHz]
720p (Frame Packing)	1280 x 720	50	37.5
720p (Frame Packing)	1280 x 720	60	45.0
1080p (Frame Packing)	1920 x1080	24	27.0
720p (Frame Packing)	1280 x 720	50	37.5
720p (Frame Packing)	1280 x 720	60	45.0
1080i (Top and Bottom)	1920 x1080	50 (25)	28.1
1080i (Top and Bottom)	1920 x1080	60 (30)	33.8
1080p (Top and Bottom)	1920 x1080	24	27.0
1080p (Top and Bottom)	1920 x1080	50	56.3
1080p (Top and Bottom)	1920 x1080	60	67.5
720p (Side by Side (Half))	1280 x 720	60	45.0
1080i (Side by Side (Half))	1920 x1080	50 (25)	28.1
1080i (Side by Side (Half))	1920 x1080	60 (30)	33.8
1080p (Side by Side (Half))	1920 x1080	50	56.3
1080p (Side by Side (Half))	1920 x1080	60	67.5
Graphic source monitor range limits	Horizontal scan rate:		15k-100kHz
	Vertical scan rate:		24-120 Hz
	Max. pixel rate:		165 MHz

Downloaded from www.Manualslib.com manuals search engine

C. MHL Digital

Modes	Resolution	V.Frequency [Hz]	H.Frequency [KHz]
VGA	*640x480	59.94/60	31.5
480i	*720x480 (1440x480)	59.94/60	15.7
576i	*720x576 (1440x576)	50(25)	15.6
480p	*720x480	59.94/60	31.5
480p_2x	*1440x480	59.94/60	31.5
576p	*720x576	50	31.3
576p_2x	*1440x576	50	31.3
720p	*1280x720	59.94/60	45.0
720p	*1280x720	50	37.5
1080i	*1920x1080	60(30)	33.8
1080i	*1920x1080	50(25)	28.1
1080p	*1920x1080	23.97/24	27.0
1080p	*1920x1080	25	28.1
1080p	*1920x1080	29.97/30	33.8
Graphic source monitor range limits	Horizontal scan rate:	15k-50 kHz	
	Vertical scan rate:	24-60 Hz	
	Max. pixel rate:	Digital: 75 MHz	

Note: * Functions vary depending on model definition.

Downloaded from www.Manualslib.com manuals search engine

Regulations and safety notices

FCC notice

This device has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

Notice: Shielded cables

All connections to other computing devices must be made using shielded cables to maintain compliance with FCC regulations.

Notice: Peripheral devices

Only peripherals (input/output devices, terminals, printers, etc.) certified to comply with the Class B limits may be attached to this equipment. Operation with non-certified peripherals is likely to result in interference to radio and TV reception.

Caution

Changes or modifications not expressly approved by the manufacturer could void the user's authority, which is granted by the Federal Communications Commission, to operate this device.

Operation conditions

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Notice: Canadian users

This Class B digital apparatus complies with Canadian ICES-003.

Downloaded from www.Manualslib.com manuals search engine

Remarque à l'intention des utilisateurs canadiens

Cet appareil numérique de la classe B est conforme a la norme NMB-003 du Canada.

Declaration of Conformity for EU countries

Acer hereby declares that this projector series is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Compliant with Russian regulatory certification

Radio device regulatory notice

Note: The regulatory information below is for models with wireless LAN and/or Bluetooth only.

General

This product complies with the radio frequency and safety standards of any country or region in which it has been approved for wireless use. Depending on configurations, this product may or may not contain wireless radio devices (such as wireless LAN and/or Bluetooth modules).

Canada — Low-power license-exempt radio communication devices (RSS-210)

a Common information
Operation is subject to the following two conditions:
1. This device may not cause interference, and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

b Operation in 2.4 GHz band
To prevent radio interference to the licensed service, this device is intended to be operated indoors and installation outdoors is subject to licensing.

List of applicable countries

This device must be used in strict accordance with the regulations and constraints in the country of use. For further information, please contact the local office in the country of use. Please see http://ec.europa.eu/enterprise/rtte/implem.htm for the latest country list.

Downloaded from www.Manualslib.com manuals search engine

CE

Acer Incorporated
8F, 88, Sec. 1, Xintai 5th Rd., Xizhi
New Taipei City 221, Taiwan

Declaration of Conformity

We,

Acer Incorporated
8F, 88, Sec. 1, Xintai 5th Rd., Xizhi, New Taipei City 221, Taiwan
Contact Person: Mr. RU Jan, e-mail: ru.jan@acer.com

And,

Acer Italy s.r.l
Via Lepetit, 40, 20020 Lainate (MI) Italy
Tel: +39-02-939-921 ,Fax: +39-02 9399-2913
www.acer.it

Declare under our own responsibility that the product:

Product:	**DLP Projector**
Trade Name:	**Acer**
Model Number:	**D1P1434**
	H8550BD/V240/HT-820

To which this declaration refers conforms to the relevant standard or other standardizing documents:

- EN55022:2010 Class B; EN 55024:2010
- EN61000-3-2:2006+A1:2009+A2:2009, Class A
- EN61000-3-3:2008
- EN 60950-1:2006/A11:2009/A1:2010+A12:2011
- Regulation (EC) No. 1275/ 2008; EN 62301:2005
- EN50581:2012

We hereby declare above product is in compliance with the essential requirements and other relevant provisions of EMC Directive 2004/108/EC, Low Voltage Directive 2006/95/EC and RoHS Directive 2011/65/EU and Directive 2009/125/EC with regard to establishing a framework for the setting of ecodesign requirements for energy-related product.

Year to begin affixing CE marking 2015.

RU Jan / Sr. Manager
Regulation, Acer Inc.

Jun, 01, 2015
Date

Downloaded from www.Manualslib.com manuals search engine

Acer America Corporation
333 West San Carlos St.,
Suite 1500
San Jose, CA 95110
U. S. A.
Tel: 254-298-4000
Fax: 254-298-4147
www.acer.com

Federal Communications Commission
Declaration of Conformity

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The following local Manufacturer / Importer is responsible for this declaration:

Product:	**DLP Projector**
Model Number:	**D1P1434**
Machine Type:	**H8550BD/V240/HT-820**
Name of Responsible Party:	**Acer America Corporation**
Address of Responsible Party:	**333 West San Carlos St. Suite 1500 San Jose, CA 95110 U. S. A.**
Contact Person:	**Acer Representative**
Phone No.:	**254-298-4000**
Fax No.:	**254-298-4147**

Downloaded from www.Manualslib.com manuals search engine